

SPARTUS® ProMIG



335DP



User's manual



WELDING EQUIPMENT SUITABLE FOR TODAY'S NEEDS

Thank you for purchasing our product!

You have made a right choice. Plasma welding and welding processes are carried out in difficult conditions that expose welding equipment to extreme tests of its strength. Only high quality equipment can ensure required reliability and performance during realization of the above-mentioned processes. SPARTUS® products are characterized by precisely such features: they are primarily reliable and durable, but they are also versatile. We listen carefully to clients' needs. Therefore, our offer covers such a wide assortment of products. Thank you very much for your trust in our company. We would like to invite you to familiarize yourself with the remaining products and offer at www.spartus.info or directly at a local distributor of SPARTUS® products.

TABLE OF CONTENTS

1. SAFE USE – HAZARDS ASSOCIATED WITH ARC WELDING AND PLASMA CUTTING	2
1.1 General safety rules	2
1.2 Electric shock can kill	2
1.3 Welding arc radiation can be dangerous	3
1.4 Vapours and gases can be dangerous	3
1.5 Noise can be harmful	4
1.6 Fire or explosion hazard	5
1.7 Other hazards	6
1.8 Other informations	6
1.9 Symbols used in instructions	7
2. ELECTROMAGNETIC FIELD (EMF)	7
3. ELECTROMAGNETIC COMPATIBILITY (EMC)	7
3.1 General informations	7
3.2 Assesment of area	8
3.3 Methods of reducing emmisions	8
4. CONFORMITY WITH STANDARDS	8
4.1 CE marking	8
4.2 Rating plate	8
5. GENERAL DESCRIPTION	9
5.1 Purpose of use	9
6. TECHNICAL SPECIFICATIONS	10
6.1 Operation, storage and transport	10
6.2 Technical parameters of device	10
7. INSTALLATION AND USE	11
7.1 Proper cooling	12
7.2 Movement and handling	12
7.3 Description of construction	12
7.4 Connecting to power supply	14
7.5 Installation – MIG/MAG welding	15
7.6 Installation – MMA welding	18
7.7 Installation – TIG welding	19
7.8 Device control panel – using	20
7.9 Remote control	32
8. MAINTENANCE	32
9. ENVIRONMENTAL PROTECTION	33
10. TROUBLESHOOTING	33



IMPORTANT!

Before using this product, read the instruction manual in its entirety, with understanding. Keep the instructions for quick reference to it if necessary. Pay special attention to safety instructions provided for your protection. In the event of any points of misunderstanding instructions, contact your supplier or supervisor.

1. SAFE USE – HAZARDS ASSOCIATED WITH ARC WELDING AND PLASMA CUTTING

Arc welding and plasma cutting are processes that can pose hazards for the operator and persons in his vicinity. The operator and his close surroundings are exposed, among others, to the risk of fire, explosion, electric shock, burning, as well as the risk of getting injured by moving parts of the device.

Once proper safety measures are provided, electric welding and plasma cutting are relatively safe processes. For this reason, it is crucial to strictly follow the valid OSH principles during welding operations.

The informations provided below do not release the operator from the obligation to follow the OSH rules that are binding in his plant/workplace.

1.1 GENERAL SAFETY RULES

Welding operators and persons working in the vicinity of the welding process should be made aware of the following hazards associated with arc welding. They should be made aware of protective measures as specified in relevant international and national standards and regulations.

1.1.1 Equipment condition and maintenance

- Check the technical condition of the device and accessories before starting to weld/plasma cutting. It is forbidden to use equipment that is unserviceable.
- Equipment damaged or defective should be immediately repaired or removed from service.

1.1.2 Operation and carrying

- Apply appropriate protective measures in the space around the zone, where welding operations are expected to be carried out.
- All equipment should be placed so that it does not present a hazard in passageways, on ladders or stairways, etc.
- Falling objects can cause injuries or kill. Protect device before accidentally falling.
- Welding equipment may be heavy (e.g. *wire*

feeder fitted with spool and harness). Care shall be taken during manual handling.

- To handle heavy elements, use hoists/trucks/transport equipment designed especially for this purpose. Make sure the weight of equipment to be handled does not exceed the admissible maximum lifting capacity of used hoist/truck/transport equipment.
- It is forbidden for unauthorized persons, especially children, to be in the vicinity of the device during its use.
- The device is not suitable for pipe defrosting.
- Device use non-compliant with its intended purpose is forbidden.

1.1.3 Training

- Only professionally trained and qualified personnel may install, operate, maintain and repair the device.
- For operators and their supervisors training is essential in: the safe use of the equipment; the processes; the emergency procedures.


1.2 ELECTRIC SHOCK CAN KILL



- Before starting to weld and during the welding process, the operator should insulate himself from the ground and the environment by means of dry and undamaged protective clothes. It is forbidden to work on wet ground.
- It is forbidden to touch SK sockets („+“ and/or „-“) when the device is in operation (*connected to a power supply source*).
- It is forbidden to touch live electric components of the device.

- Power supply must never be connected before the accessories of SK sockets/connectors are properly installed in the device.
- Use dry and undamaged welding gloves and protective clothing, in order to ensure proper insulation of the body. It is forbidden to touch with a bare hand any elements that are parts of an electric circuit.
- The operator must always make sure that there is a good electric connection of the return conductor to the element to be welded. The connection should be located as close to the welding zone as possible.
- Maintain the electrode grip, the welding torch, the chassis ground clamp, welding cables and the welding machine in proper technical condition that ensures safe operation. Damaged cable insulation should be replaced with new insulation.
- Never dip an electrode into water, to cool it down.
- When working above the floor level (at a height), use a safety harness to protect yourself against falling, in the case of potential electric shock.
- Exercise special caution, when using the device in small rooms or in rooms with elevated humidity levels.

1.3 WELDING ARC RADIATION CAN BE DANGEROUS



The arc generates:

- ultraviolet radiation (*can damage skin and eyes*);
- visible light (*can dazzle and impair vision*);
- infrared (*heat*) radiation (*can damage skin and eyes*).

Such radiation can be direct or reflected from surfaces such as bright metals and light coloured objects.

1.3.1 Eye and face protection

- Use welder's helmet/shield with an appropriate filter to protect you face and eyes against sparks and welding arc radiation.
- The shield / helmet should provide eye and face protection against injuries that may result in welding spatters.
- Welding helmet/shield should be made in accordance with applicable standards.


1.3.2 Body protection

- The body should be protected by suitable clothing in accordance with applicable standards.
- Use appropriate protective clothing made of durable and fire-resistant material, to ensure proper skin protection.
- The use of neck protection can be necessary against reflected radiation.

1.3.3 Protection of persons in the vicinity of an arc

- Protect the remaining personnel present in the vicinity of welding works against negative impact of arc radiation and welding splatters. Warn them about the hazard resulting from exposure to the welding arc. In the vicinity of an arc, non-reflective curtains or screens should be used to isolate persons from the arc radiation. A warning, e.g. a symbol for eye protection, should refer to the hazard of arc optical radiation. Welder's assistants should also wear appropriate protective clothing.

1.4 VAPOURS AND GASES CAN BE DANGEROUS



Arc welding and allied processes produce welding fume which may pollute the atmosphere surrounding the work. Welding fume is a varying mixture of airborne gases and fine particles which, if inhaled or swallowed, constitute a health hazard.

The degree of risk is depend on:

- the composition of the fume;
- the concentration of the fume;
- the duration of exposure.

A systematic approach to the assessment of exposure is necessary, taking into account the particular circumstances of the operator and the ancillary worker who can be exposed.

Welding fume may be controlled by a wide range of measures, e.g. process modifications, engineering controls, methods of work, personal protection and administrative action.

First it is necessary to consider whether exposure can be prevented by eliminating the generation of welding fume altogether. Where this cannot be done, measures for reducing the quantity of welding fume generated should be investigated, after which the control of welding fume at source should be considered. The use of respiratory equipment should not be contemplated until all other possibilities have been eliminated. Normally, respiratory protective equipment should be used only as an interim measure. However, there cannot be a situation in which, in addition to ventilation, the use of personal protection is necessary.

1.4.1 VAPOURS AND GASES. ADDITIONAL PRECAUTIONS

- Welding operations can involve generation of vapours and gases that are hazardous to health. Inhaling the vapours should be avoided. Keep your head away from vapours during welding operations. Ensure proper ventilation and/or mechanical welding exhaust draught to keep vapours and gases away from the breathing zone.
- When welding is carried out in a confined space, operators should only be permitted to weld when other persons, who have been instructed and who are able to react

in case of an emergency, are in the immediate vicinity.

- In closed rooms or in certain circumstances during outdoor operations, it may be required to use individual equipment for the protection of the welder's airways, e.g. a respirator. Additional safety measures are also required when galvanized steel is welded.
- Welding operations must not be performed in the vicinity of chlorinated hydrocarbons generated during degreasing, cleaning or spraying. Heat and radiation generated by the arc may enter into a reaction with vapours of solvents, which may lead to the formation of phosgene – a highly toxic gas.
- The shielding gas used during arc welding may force the air out of a room. This may lead to a health hazard or even death. Proper ventilation, especially in closed rooms, should always be provided, to ensure appropriate amount of air that is indispensable for safe breathing.

1.5 NOISE CAN BE HARMFUL



In the welding environment, damaging levels of noise can exist. Continued exposure to a high noise level on the unprotected ear is injurious. The noise levels should be reduced to the lowest practicable level.

High levels may be tolerated for very short periods by wearing adequate ear protection in accordance with the national or local regulation. In case of doubt, checks by an expert should be made to establish noise levels in any particular environment, and, if these are in excess of the prescribed limit, one of the following alternatives may apply:


- a) insulation of the noise source as far as possible, e.g. by fitting silencers or sound proof enclosures,
- b) insulation of the operator from the noise

- source,
- c) effective maintenance of sound protection devices,
- d) indication as „ear protection areas“ where applicable,
- e) restriction of entry to these „ear protection areas“ to authorized persons,
- f) protect your hearing with appropriate personal protection measures, e.g. earplugs or hearing protectors.

1.6 FIRE OR EXPLOSION HAZARD

Arc welding and allied processes can cause fire and explosions. Precautions should be taken to prevent these hazards.

1.6.1 Fire hazard




- Before setting to perform welding operations, ensure that elements involving fire hazard are removed from the zone where welding operations will take place. If it is impossible, protect all flammable elements against the impact of sparks. Remember that sparks and hot metal may penetrate through small cracks and openings into the adjacent area.
- Avoid welding in the vicinity of hydraulic conduits.
- The welding arc throws sparks and splatters out. Welders should wear clean and dry protective clothing (*staining with oil should be avoided in particular*) such as welding gloves, welder's apron, welder's trousers, welder's boots, protective hood/cap, etc.
- When welding operations are not carried out, make sure that no part of the electrode comes into contact with the workpiece or protective earthing. Accidental contact may lead to overheating and create a fire hazard.
- The fire extinguisher should be ready for use and located in an easily accessible place.
- The surroundings of the work should be observed for an adequate period after its termination.
- „Hot spots“ and immediate surroundings should be observed until their temperature has dropped to normal.

1.6.2 Explosion hazard

It is forbidden to heat up, cut or weld tanks, barrels or containers that contained toxic or flammable materials. For there is an explosion hazard, even if the containers have been emptied and cleaned.

1.6.3 Use of cylinders with shielding gas



In case compressed gases are used in the work place, apply special safety measures to prevent dangerous situations.

- Use gas cylinders with appropriate shielding gas, foreseen for a particular process. Additional equipment (pressure regulator, hoses, connectors) should be in good technical condition. A gas cylinder and accessories should have the required valid attestations and approvals for use.
- Gas cylinders should always be stored in vertical position, fixed to an undercarriage or permanent support.
- Gas cylinders should be placed far away from areas, where they could be exposed to the risk of being overturned or suffering physical damage.
- Ensure gas cylinders are at a safe distance from places where electric welding or cutting operations are to be performed, away from other sources of heat, sparks or flames.
- Care shall be taken to prevent gas cylinders in the vicinity of the workpiece becoming part of the welding circuit.
- Never allow the electrode, electrode holder or any other live electric part to get in contact with the gas cylinder.
- Keep your face and head away from the


cylinder valve socket when the valve is being opened.

- Special valve shield should always be installed during cylinder transportation or when the cylinder is not used.

1.7 OTHER HAZARDS


Arc welding and allied processes carrying other hazards not listed before.

1.7.1 Burns



- Never touch hot parts with bare hands.
- Before handling an element, wait until it cools down.
- Use appropriate tools to grip and handle hot elements and wear special welding gloves and clothing that protects against burns.

1.7.2 Plasma arc is dangerous



Highly concentrated plasma arc poses a hazard for health and life. It is forbidden to aim plasma arc at people.


1.7.3 Welding wire can cause injuries



Accidental pressing of the button on the welding torch can cause welding wire to advance in an uncontrolled manner. The welding wire tip may be sharp.

Never aim the burner tip of the welding torch at your face, eyes or other people.

1.7.4 Moving elements can be dangerous



All protective elements and device housing should be in place and in good technical condition. Keep your hands, hair, clothes and tools away from gear wheels, fans and other moving parts during their operation.

Do not bring your hands close to fan motors. It is forbidden to stop a fan by pressing its axis.

1.7.5 HF – high frequency ignition may cause interference



As welding by the TIG method or plasma cutting involves high frequency ignition, it can interfere with mobile phones, radio equipment, TV equipment or improperly protected computers and industrial robots, which leads to total disabling of such devices.

1.8 OTHER INFORMATIONS

When performing welding work, you must apply equally to the health and safety requirements contained in the current normative acts, applicable in your country.

**WARNING!**

The maximum voltage of 15kV. Accidental pressing of the microswitch results in unintentional arc ignition. Never bring a bare hand close to the electrode, when the device is connected to a power source.

1.9 SYMBOLS USED IN INSTRUCTIONS

We use this symbol to pay your attention about important information.

2. ELECTROMAGNETIC FIELDS (EMF)

Electric current flowing through any conductor causes localized electric and magnetic fields (EMF). All welders should use the following procedures in order to minimize the risk associated with exposure to EMF from the welding circuit:

- Route the welding cables together – secure them with tape when possible.
- Place your torso and head as far away as possible from the welding circuit
- Never coil welding cables around your body.
- Do not place your body between welding cables. Keep both welding cables on the same side of your body.
- Connect the return cable to the workpiece as close as possible to the area being welded.
- It is forbidden to sit or lean on power source while working.
- Do not weld whilst carrying the welding power source or wire feeder.

WARNING!

The electromagnetic field (EMF) generated during welding (and allied processes) may interfere with the operation of implanted medical devices for example: cardiac pacemakers. Persons with implanted medical devices such as cardiac pacemakers are obliged to consult a doctor before starting to weld/plasma cutting and to exercise special caution during work. It is forbidden for such persons to be present in the vicinity of the place where welding/plasma cutting processes are realized without previous consultation of a doctor.

3. ELECTROMAGNETIC COMPATIBILITY (EMC)**WARNING!**

This Class A equipment is not intended for use in residential locations where the electrical power is provided by the public low-voltage supply system. There can be potential difficulties in ensuring electromagnetic compatibility in those locations due to conducted as well radiated radio-frequency disturbances.

3.1 GENERAL INFORMATIONS

The user is responsible for installing and using the arc welding equipment according to the manufacturer's instructions. If electromagnetic disturbances are detected, then it shall be the responsibility of the user of the arc welding equipment to resolve the situation with the technical assistance of the manufacturer. In some cases this remedial action may be as simple as earthing the welding circuit. In other cases, it could involve constructing an electromagnetic screen enclosing the welding power source and the work complete with associated input filters. In all cases electromagnetic disturbances shall be reduced to the point where they are no longer troublesome.

Welding and plasma cutting processes may emit additional interferences. User is responsibility for the interferences caused by welding and plasma cutting.

3.2 ASSESMENT OF AREA

Before installing arc welding equipment, the user shall make an assessment of potential electromagnetic interferences in the surrounding area. The following shall be taken into account:

- a) other supply cables, control cables, signaling and telephone cables, above, below and adjacent to the arc welding equipment,
- b) radio and television transmitters and receivers,
- c) computer and other control equipment,
- d) safety critical equipment, for example guarding of industrial equipment,
- e) the health of the people around, for example the use of pacemakers and hearing aids,
- f) equipment used for calibration or measurement,
- g) the immunity of other equipment in the environment. The user shall ensure that other equipment being used in the environment is compatible. This may require additional protection measures.
- h) the time of day that welding or other activities are to be carried out.

The size of the surrounding area to be considered will depend on the structure of the building and other activities that are taking place. The surrounding area may extend beyond the boundaries of the premises.

3.3 METHODS OF REDUCING EMMISIONS

Methods of reducing electromagnetic interference are listed in detail in the standard EN 60974-9 – „Arc welding equipment – Part 9: Installation and use“.

4. CONFORMITY WITH STANDARDS

SPARTUS® ProMIG 335DP is in conformity with the relevant Union harmonization legislation:

LVD 2014/35/UE

Low Voltage Directive

EMC 2014/30/UE

Electromagnetic Compatibility Directive

harmonized standards:

EN 60974-1

Arc Welding Equipment – Part 1: Welding Power Sources

4.1 CE MARKING

CE marking is placed on the nameplate of device and/or on the front panel of device.



4.2 RATING PLATE

Rating plate and serial number are located on the device case.

5. GENERAL DESCRIPTION

SPARTUS® ProMIG 335DP

It is high-end, modern inverter welding machine enabling:

- MIG/MAG synergy welding with double pulse
- MIG/MAG synergy welding with pulse
- MIG/MAG synergy welding
- MIG/MAG welding in manual setting mode
- TIG Lift welding
- MMA coated electrode welding.

At a high 60% duty cycle, the maximum welding current is 300A. It is powered from three phase 400V source power.

A high-class, built-in four-roller feeder ensures stable welding wire feeding. ProMIG 335DP with a liquid cooler is mounted on a special welding cart that ensures full mobility of the set.

MIG welding

ProMIG 335 with synergistic system for MIG / MAG welding allows to select the type and diameter of the welding wire. This makes it possible to weld: steel, stainless steel, aluminum, self-shielding wire welding and braze welding. In addition, the device has a number of functionalities supporting the welding process:

- 2T/4T / s4T / SPOT mode
- Pre Gas
- Post Gas
- Slow Feed
- Burn Back.

For advanced synergic MIG welding with pulsation and MIG welding with double pulsation, it is possible to set:

- delta pulse current
- pulse frequency
- puls duty
- base current.

MIG/MAG welding in manual setting mode makes ProMIG 335DP perfect machine for the most demanding user. An additional advantage is also the possibility of welding with the Spool Gun.

TIG welding

Thanks to the solutions used, the ProMIG 335DP also enables TIG Lift method welding with the possibility to select the operating mode of the 2T/4T microswitch and function settings: Down Slope and Post Gas.

MMA welding

The process of joining metals in this method is additionally supported by functions: Arc Force and Hot Start.

SPARTUS® ProMIG 335DP is equipped with 10 job records, allows for quick selection of previously saved welding parameters.

Modern design, bright and legible LCD function panel combined with high-class components makes the SPARTUS® ProMIG 335DP one of the best machines in its class on the market.

SPARTUS® Pro line professional devices thanks to its quality, warranty and technical support are perfect for the production sector and industry.

5.1 PURPOSE OF USE

SPARTUS® ProMIG 335DP welding devices are designed for:

- Metal Inert Gas welding (MIG) or Metal Active Gas welding (MAG),
- Tungsten Inert Gas welding (TIG),
- Manual Metal Arc welding (MMA).

6. TECHNICAL SPECIFICATIONS

6.1 OPERATION, STORAGE AND TRANSPORT

Conditions during operation, storage and transport

Range of ambient air temperature during operation	-10°C to +40°C
Relative humidity of the air	up to 50% at +40°C up to 90% at +20°C
Ambient air	free from abnormal amounts of dust, acids, corrosive substances etc. other than those generated by the welding process
Base of the welding power source inclined	no more than 10°
Range of ambient air temperature during storage and transport	-20°C to +55°C
Height above sea level	≤1000 m



Duty cycle (def.)

Duty cycle is the time during which You can weld or cut at a certain load without causing overload. It is expressed in percent for period of complete cycle which equals 10 minutes. For example: 60% duty cycle means that for 6 minutes device can operate at given load, after that required 4 minutes time break (no-load operation).



Protection against overheating (def.)

Security system from overheating will turn on when the welder is over-heat (possibility of welding is turned off, abnormal indicator on front panel lights up). In such a situation, You should not turning off the unit immediately. Wait some time until fan cools the unit. Time to return to the state from overheating can take up to approx. 15 minutes.



The device has a degree of protection IP21S. Which means that it is intended to be used in closed and covered areas and suitable for use outdoors. However it is not designed to be used outdoor during precipitation if it is not covered.

6.2 TECHNICAL PARAMETERS OF DEVICE

ProMIG 335DP

Input	~3 × 400V ± 10% 50 / 60 Hz
Welding current MIG [A]	10 – 300
Duty cycle MIG [%]	60

MIG PARAMETERS

Wire feeder	built-in, 4-roll
Wire diameter Ø [mm]	0.8 / 1.0 / 1.2
Welding wire spool	≤ 15[kg], ø200/300
Wire feeding speed [m/min]	2 – 24
Wire feeding test	✓
2T / 4T control	✓
Welding with pulsation 1P and 2P	✓
Spool Gun	✓
Synergic	✓

TIG PARAMETERS

TIG welding mode	TIG DC
TIG welding current [A]	10 – 300
Duty cycle [%]	60
Gas pre flow [s]	0 – 5
Up slope [s]	0 – 10
Down slope [s]	0 – 10
Gas post flow [s]	0 – 10
2T/4T control	✓
Arc ignition	LIFT

MMA PARAMETERS

MMA welding mode	✓
MMA welding current [A]	10 – 300
Duty cycle [%]	60
Hot Start	0 – 10
Arc Force	0 – 10

OTHER

Max. current consumpition [A]	MIG 14.8 / TIG DC 11.5 / MMA 16.3
Power factor (cosφ)	0.9
Insulation class	H
Protection class	IP21S
Weight [kg]	55
Dimensions [mm]	930 x 490 x 940

7. INSTALLATION AND USE

WARNING!

SPARTUS® ProMIG 335DP machines are intended for professional and industrial applications. Installation and use of the device may only be carried out appropriately trained professionals.

*It is **forbidden** to grinding and/or carrying out other locksmith works or mechanical working of metal in the vicinity of the ventilation opening of unit.*



Qualified person (def.)

A person who has gained the relevant technical education, training took place and / or gained experience to perceive the risk and avoid hazards during use of the product (IEC 60204-1).

7.1 PROPER COOLING


The unit should be placed stable on a dry and flat surface. Avoid too much slope and slippery surfaces. Check regularly that the vents (inlet, outlet) are not covered. The minimum distance between the welder vents and walls should be 50cm.

7.2 MOVEMENT AND HANDLING


The source is available on a specially constructed welding cart (platform), equipped with road wheels and a transport handle.

The cart should be moved by means of a specially designed transport handle on an even and flat surface. If transport handle (device/cart) or cart wheels are damaged, then it needs to be repaired at an authorized service center.

7.3 DESCRIPTION OF CONSTRUCTION




7.3.1 Welding source




- | | | | |
|---|--|----|--------------------------|
| 1 | Control panel | 6 | SK _n + socket |
| 2 | SK _n - socket | 7 | MIG torch EURO connector |
| 3 | TIG remote connection plug | 8 | Gas inlet |
| 4 | MIG torch polarity change power connection | 9 | Power cable |
| 5 | TIG torch gas connector | 10 | Toggle switch ON/OFF |

7.3.2 Cooler



- | | | | |
|----|-------------------------|----|-------------------------|
| 11 | Water inlet | 13 | Water outlet for TIG |
| 12 | Backwater inlet for TIG | 14 | Water level calibration |

7.3.3 Wire feeder



- | | | | |
|----|------------------------------|----|-------------------------|
| 15 | Spool holder | 18 | Wire feeder inlet guide |
| 16 | Wire feed tension adjustment | 19 | Wire feeder rollers |
| 17 | Wire feed tension arms | | |


7.4 CONNECTING TO POWER SUPPLY

Requirements for power network parameters (voltage, permissible range of mains voltage fluctuations etc.) are given in the table with technical parameters of device and on the rating plate of welding machine.

Before connecting the unit to the power source:

- Check whether the parameters comply with the requirements for unit.
- Check: mechanical condition of the power cord and plug. The connection status of the power cord with plug and unit (loose not allowed). If the power cord or plug is damaged or loose connection is between them, it is forbidden to connect the welder until fault has been rectified.
- The welder machine can be connected to the network only when the power socket is properly grounded.

7.4.1 Scheme of connection of power plug connector 400V



WARNING!

It is forbidden bridging PE and N cables. it may cause serious risk of electric shock!

In some cases, colours of power cords may vary from those shown on diagram. For example when the device has a four-wired three phase power cord. In this case, the PE protective conductor (yellow-green) must be connected to the terminal which is provided for it \perp . And the other cables must be connected to the appropriate terminals L1, L2, L3. If one of the wires colour is blue – do not connect it to the terminal N – neutral. In this case blue cable is one of the phase conductors L1, L2, L3.

7.5 INSTALLATION – MIG/MAG WELDING



Before installation the welding wire spool, make sure that weight and dimension of the spool meet the requirements set out in the table with technical data of device.



*Before connecting hardware and shielding gas to the device, make sure that the device is disconnected from power source and switch **10** is in the OFF position.*

7.5.1 Connecting the gas cylinder

1. The cylinder with appropriate shielding gas, should be placed in a vertical position and secured against falling over in accordance with safety requirements (*for gas cylinders under the influence*).
2. Make sure that the valve cylinder is closed.
3. Connect properly gas regulator to cylinder valve.
4. Connect the gas hose into gas regulator outlet. Secure the connection with a special clamp.
5. Connect the gas hose to the device **8**.



The valve in the cylinder must be opened immediately before welding. After welding it should be closed.

7.5.2 Welding wire spool installation

1. Place the wire spool on mounting mechanism. Pay attention to direction of unwinding welding wire (*basic criterion – minimum bending radius of wire, linearly to wire inlet guide **18***). Locking pin should be placed in special hole in wire spool.
2. Lock the mounting block in the mounting bracket.
3. Unlock tension knob **17**. Check if the feed rolls are proper to type and diameter of welding wire.

- Pass end of wire through wire inlet guide (18), through groove of drive roll and EURO socket guide. The end of welding wire should leave a distance approx. 10mm beyond outline of EURO socket (7).
- Lock tension knob (17).

7.5.3 MIG/MAG gun installation

- Connect properly MIG gun plug to EURO socket (7).
- Pay special attention to the correct fit of the control pins and input welding wire from wire feeder to the wire inlet guide in MIG gun.
- Tighten the MIG gun plug nut clockwise until it stops. Incorrectly mounted MIG gun can cause damage.



7.5.4 Assembling welding wire into liner

- Connect properly MIG gun into welding machine (see 7.5.3).
- Dismantle the torch consumables (gas nozzle, contact tip).
- Connect the welder into power supply. Turn on the machine using power switch (10).
- Expand MIG gun as straight as it is possible.
- Using the button (G) (pt 7.8) start wire feeding into MIG gun liner. Make sure that pressure tension of feeder rolls is suitable. Remember! Never point torch into direction eyes / face or others.
- When wire end comes out to a distance approx. 30mm beyond the torch outline, release the button (G) (pt 7.8) to stop feeding wire.
- Assemble welding wire into liner (gas nozzle, contact tip).
- Cut off the end of wire properly.

7.5.5 Device installation – MIG/MAG welding




Before connecting hardware and shielding gas to the device, make sure that the device is disconnected from power source and switch (10) is in the OFF position.



For most applications during MIG/MAG welding the polarity of the welding should be positive, '+' on the EURO socket and negative, '-' on the return cable.

- Connect the gas hose to the machine.
- Connect return cable into SK socket, "-" (2) and the mass clamp to the welded part.
- Plug the MIG welding gun into device (see 7.5.3).
- Make sure that all threaded connections are not loose and that the shielding gas connection is tight.
- Connect the machine to the power supply in accordance with appropriate guidelines (see 7.4).
- Turn on the device by setting the switch (10) to ON position.
- Insert the welding wire to the handle (see 7.5.4).
- Open the valve in the gas cylinder and set the appropriate value for the shielding gas flow.
- The machine is ready for welding.



7.5.6 Installation & operation for SPOOL GUN

1. Insert the earth cable plug into the SK_{,-} socket (2) on the front of the machine and twist to tighten.
2. Insert the polarity switch cable plug into SK_{,+} socket (6) on the front of the machine and tighten it.
3. Plug the Spool Gun into the euro connect socket (7) on the front panel and tighten. **IMPORTANT:** When connecting the torch be sure to tighten the adaptor nut completely tight. A loose connection can result in arcing between the gun and machine connector and that causes serious damage to both the torch and machine connections.
4. Connect the Spool Gun control cable to the air socket for Spool Gun (3) on the wire feeder side panel.
5. Connect the gas regulator to the gas cylinder and connect the gas line to the regulator.
6. Connect the gas line to gas connector (8) on the rear panel.
7. Connect the power cord of welding machine with the outlet on electrical box.
8. Remove the spool cover by pressing button and lifting off the cover.



9. Place a spool of wire inside the spool holder on post.



10. Feed the wire through the drive rolls and into the inlet guide tube. Tighten the wire tension swing arm.



11. Pull the trigger to drive the wire down the neck until it exits the contact tip.



12. Carefully open the gas cylinder valve and set the required gas flow rate.
13. Set welding parameters using the knobs as shown on digital displays.

7.6 INSTALLATION – MMA WELDING




Before connecting hardware and shielding gas to the device, make sure that the device is disconnected from power source and switch **(10)** is in the OFF position.



The welding polarity depends on the type of electrodes used. Before connecting the cables refer to the requirements specified by the manufacturer of electrodes.

1. Connect electrode cable plug into SK socket **(2)** or **(3)**.
2. Connect return cable plug into appropriate SK socket **(2)** or **(3)**.
3. Connect earth clamp into workpiece.

4. Connect the welder into power supply in accordance with appropriate guidelines (see 7.5).
5. Turn on the welder by setting power switch **10** in the ON position.
6. The device is ready to weld.



7.7 INSTALLATION – TIG WELDING



Before connecting hardware and shielding gas to the device, make sure that the device is disconnected from power source and switch **10** is in the OFF position.

7.7.1 Connecting the gas cylinder

1. The cylinder with appropriate shielding gas, should stand upright and be secured against tipping over in accordance with safety requirements.
2. Make sure that the valve cylinder is closed.
3. Connect properly gas regulator to cylinder valve.
4. Connect the gas hose into gas regulator outlet. Use special clamps to seal connection.
5. Connect gas hose to the connection on the device **8**.




The valve in the cylinder must be opened immediately before welding.
After welding it should be closed.

7.7.2 TIG torch installation


1. Connect properly TIG torch plug into SK_{„-“} **2**.
2. Connect properly TIG torch control plug into control socket **3**.
Pay attention to suitable fitting of control pins.
3. Connect gas hose into shield gas connector **5** at the front panel.

7.7.3 Connecting the device

1. Connect the gas pipe to the device (see 7.5.1).
2. Connect the welding holders TIG (see 7.7.2).
3. Connect the return line to the SK socket_{„+“} **3**, and the mass clamp to the welded element.
4. Connect the welding device to the power source in accordance with the guidelines (see 7.4).
5. Turn on the device by setting switch **10** in the ON position.
6. The device is ready to work.



7.8 DEVICE CONTROL PANEL – USING



- A** Welding mode button
- B** Welding adjustment knob 1
- C** Gas test button
- D** Function button
- E** Cooling mode button: gas/liquid
- F** Welding adjustment knob 2
- G** Button for inserting the welding wire into the MIG gun
- H** Save/recall JOB program button

7.8.1 Detailed description of selected buttons on the panel

A WELDING MODE BUTTON:

- **MIG Synergic**
- **MIG Pulse**
- **MIG Dual Pulse**
- **MIG Manual**
- **TIG Lift**
- **MMA**

B WELDING ADJUSTMENT KNOB 1

Press it to select parameters and turn it to adjust values, such as welding current. In function interface, turn it to select parameters.


D FUNCTION BUTTON

Press it to select parameters or enter the function interface.

F WELDING ADJUSTMENT KNOB 2

Press it to select parameters and turn it to adjust values.

MMA DISPLAY INTRODUCTION




A MMA WELDING MODE BUTTON

H WELDING ADJUSTMENT KNOB 1: welding current


I WELDING ADJUSTMENT KNOB 2: Hot Start or Arc Force

TIG LIFT DISPLAY INTRODUCTION



- A TIG Lift WELDING MODE BUTTON
- B WELDING ADJUSTMENT KNOB 1: welding current
- D FUNCTION BUTTON: press it to enter the function interface
- E COOLING MODE BUTTON: press to select water cooling
- F WELDING ADJUSTMENT KNOB 2: Down Slope


FUNCTION INTERFACE – TIG



1. **Trigger mode:** 2T/4T
2. **Down Slope time:** 0~10s.
3. **Post gas:** 0~10s.

Course of TIG welding process (2T)


During TIG function 2T, you can not set the current parameters of the initial and final current.



- 0 Press the gun switch and hold it. Electromagnetic gas valve is turned on. The shielding gas starts to flow.
- 0-1 Pre-gas time.
- 1 Initiation of the welding arc.
- 1-2 Arc is ignited and the output current rises to the setting welding current from the min. welding current.
- 2-3 During the whole welding process, the gun switch is pressed and held without releasing.
- 3 Release the gun switch, the welding current will drop in accordance with the selected down-slope time.
- 3-4 The current drops to the minimum welding current from the setting current, and then arc is turned off.
- 4 Termination arc welding.
- 4-5 Post-gas time, after the arc is turned off. You can adjust it (0.1~10s) through turning the knob on the front panel.
- 5 Electromagnetic valve is closed and stop argon flowing. Welding is finished.


Course of TIG welding process (4T)

During TIG 4T, it is possible to preset the current value of the initial and final current. With this feature, you can prevent flooding at the beginning of the weld and fill the crater formed at the end of the weld.





- 0 Press and hold the gun switch, Electromagnetic gas valve is turned on. The shielding gas starts to flow.
- 0-1 Pre-gas time.
- 1-2 Arc is ignited at t1 and then output the setting value of start current.
 - 2 Loosen the gun switch, the output current slopes up from the start current.
 - 2-3 The output current rises to the setting value, the upslope time can be adjusted.
- 3-4 Welding process. During this period, the gun switch is loosen.
 - 4 Press the torch switch again, the welding current will drop in accordance with the selected down-slope time.
- 4-5 The output current slopes down to the crater current. The downslope time can be adjusted.
- 5-6 The crater current time.
- 6 Loosen the gun switch, stop arc and keep on argon flowing.
- 6-7 Post-gas time.
- 7 Electromagnetic valve is closed and stop argon flowing. Welding is finished.

MIG MANUAL DISPLAY INTRODUCTION




- A MIG Manual WELDING MODE BUTTON
- B WELDING ADJUSTMENT KNOB 1: wire feeding speed
- C GAS TEST BUTTON
- D FUNCTION BUTTON: press it to enter the function interface
- E COOLING MODE BUTTON: press to select water cooling
- F WELDING ADJUSTMENT KNOB 2: inductance
- G BUTTON FOR INSERTING THE WELDING WIRE INTO THE MIG GUN

FUNCTION INTERFACE – MIG Manual




1. **Trigger mode:** 2T/4T / SPOT
2. **Pre Gas:** 0~5
3. **Post Gas:** 0~10
4. **Burnback:** 0~10
5. **Slow Feed:** 0~5
6. **Spool gun:** ON/OFF
7. **SPOT welding time:** 0.5~10s


SPOT weld trigger mode



MIG (DUAL) PULSE DISPLAY INTRODUCTION



- (A)** MIG Pulse/MIG Dual Pulse WELDING MODE BUTTON
- (B)** WELDING ADJUSTMENT KNOB 1: welding current
- (C)** GAS TEST BUTTON
- (D)** FUNCTION BUTTON: press it to enter the function interface
- (E)** COOLING MODE BUTTON: press to select water cooling
- (F)** WELDING ADJUSTMENT KNOB 2: inductance, arc length adjustment
- (G)** BUTTON FOR INSERTING THE WELDING WIRE INTO THE MIG GUN

FUNCTION INTERFACE – MIG (Dual) Pulse

PARAMETER	
MODE	2T
WIRE MATERIAL	Al-Mg Solid-cored
WIRE DIAMETER	0.9mm
TYPE OF GAS	Ar
PRE FLOW	10.0s

MIG Dual Pulse Water

PARAMETER	
POST FLOW	10.0s
BURNBACK	10
SLOW FEED	10s
DELTA PULSE CURRENT	156A
PULSE FREQUENCY	250Hz


MIG Dual Pulse Water

PARAMETER	
PULSE DUTY	90%
BASE CURRENT	10
ARC LENGTH	


MIG Dual Pulse Water

1. **Trigger mode:** 2T/4T / s4T(4T+) (SPOT for MIG Pulse)
2. **Wire material:** Fe-metal solid-cored / Fe-metal flux-cored / SS-metal solid-cored / CuSi / Al-Mg solid-cored / Al-Si solid-cored / Al 99.5 solid-cored / SS-metal flux-cored / CuAl
3. **Wire diameter:** 0.8 ~1.2mm
4. **Shield gas:** CO₂ / Ar / 98%Ar+2%CO₂ / 80%Ar+20%CO₂
5. **Pre Gas:** 0~5s
6. **Post Gas:** 0~10s

- 7. **Burnback:** 0~10
- 8. **Slow Feed time:** 0~5s
- 9. **Delta pulse current:** 20~200A (only be available in Dual Pulse welding mode)
- 10. **Pulse frequency:** 0.5~3Hz (only be available in Dual Pulse welding mode)
- 11. **Pulse duty:** 10~90% (only be available in Dual Pulse welding mode)
- 12. **Base current arc length:** -10~10 (only be available in Dual Pulse welding mode)





MIG SYNERGY DISPLAY INTRODUCTION



- (A) MIG SYN WELDING MODE BUTTON
- (B) WELDING ADJUSTMENT KNOB 1: wire feeding speed
- (C) GAS TEST BUTTON
- (D) FUNCTION BUTTON: press it to enter the function interface
- (E) COOLING MODE BUTTON: press to select water cooling
- (F) WELDING ADJUSTMENT KNOB 2: inductance, arc length adjustment
- (G) BUTTON FOR INSERTING THE WELDING WIRE INTO THE MIG GUN

FUNCTION INTERFACE – MIG Synergy



1. **Trigger mode:** 2T/4T / SPOT weld
2. **Wire material:** Fe-metal solid-cored / Fe-metal flux-cored / SS-metal solid-cored / CuSi
3. **Wire diameter:** 0.8 ~1.2mm
4. **Shield gas:** CO₂ / Ar / 98%Ar+2%CO₂
5. **Pre Gas:** 0~5s
6. **Post Gas:** 0~10s
7. **Burnback:** 0~10
8. **Slow Feed time:** 0~5s

Synergy programs


MIG SYNERGY

WELDING WIRE	WIRE DIAMETER (mm)	SHIELDING GAS
Fe-metal solid cored	0.8 - 1.2	CO ₂
Fe-metal Flux cored	1.0 - 1.2	CO ₂
Ss-metal solid cored	1.0 - 1.2	98%Ar + 2%CO ₂
CuSi	1.0 - 1.2	100%Ar

MIG PULSE / DUAL PULSE

WELDING WIRE	WIRE DIAMETER (mm)	SHIELDING GAS
Fe-metal solid cored	0.8 - 1.2	80%Ar + 20%CO ₂
Fe-metal Flux cored	1.2	80%Ar + 20%CO ₂
Ss-metal solid cored	1.0 - 1.2	98%Ar + 2%CO ₂
CuSi	0.8 - 1.2	100%Ar
Al-Mg solid cored	1.0 - 1.2	100%Ar
Al-Si solid cored	1.0 - 1.2	100%Ar
Al 99.5 solid cored	1.2	100%Ar
Ss-metal Flux cored	1.2	80%Ar + 20%CO ₂
CuAl	1.2	100%Ar

JOB PROGRAM CONTROL PANEL



- (J1) PARAMETERS DISPLAY: set the parameters of the selected program
- (B) WELDING ADJUSTMENT KNOB 1: delete the parameters
- (H) JOB BUTTON: press it for 3s to enter JOB programs and press it for 1s to save parameters.
- (J2) JOB NUMBER DISPLAY
- (F) WELDING ADJUSTMENT KNOB 2: load the selected JOB program number

Save / activate / delete memory channels on the device

The device has 10 memory channels on which you can save the most-used machine settings. After selecting the appropriate parameters, press the button (H) for 1s. The settings will be saved to the first free channel.

Calling up saved memory channels consists of holding the button for 3s (H). The memory channel number is selected by turning the knob (F). The memory channel is activated by pressing the knob. The saved memory channel is deleted with the knob (B).


SYSTEM SETTING PANEL



Press the functional parameter button (D) and hold it for 3s to enter the system interface. Here you can adjust the language, the unit and the brightness setting by left and right welding adjustment knob.

7.9 REMOTE CONTROL IN WELDING TIG METHOD

Remote control is carried out using a potentiometer located in the handle of the torch or by using wired foot pedal.



POTENTIOMETER



WIRED FOOT PEDAL

8. MAINTENANCE

WARNING!

Before performing any maintenance or repairing of device, disconnect welding machine from the power source and wait at least 5 minutes. The voltage accumulated in capacitors should be discharged at this time to a safe level. But even after that operation you should be careful.



Make sure that the device is disconnected from the power source, and switch 10 is in the OFF position, before connecting accessories and shielding gas to the device.

Maintenance and repair work may be performed only by qualified personnel with the appropriate permissions. Regular maintenance provides adequate service life and trouble-free operation of the device.

Routine maintenance (daily: before use/installation):

- Perform a visual inspection of the housing, knobs, control panel.
- Inspect (visual inspection) the power cord and power plug. Check the insulation of the cable.
- Check the condition of welding cables and their connectors. If cable insulation is damaged – replace it. If connection is too loose – eliminate backlash.
- Check if cooling fan is working properly.
- Make sure that all vents are not obstructed.


At least once a month:

- Regularly remove dust from inside of the machine. Use for this compressed air. The pressure should be sufficiently low so as not to damage small components inside the machine. If in the workplace, dust levels are high. You should clean machine often.
- Perform inspection of connection of internal electrical components. If anywhere the joints are loose, tighten them.

Once a year:

- You should send device to an authorized service center for an interim review.

9. ENVIRONMENTAL PROTECTION



The product must not be disposed of into an ordinary waste container. It is totally forbidden to dispose of electric or electronic equipment marked with a crossed-out trash can symbol by throwing it into ordinary waste containers. According to the WEEE directive (directive 2012/19/UE), binding within the European Union, such products should be disposed of according to local regulations.

We hereby inform the client that, according to the regulations, each commodity is burdened with waste disposal costs (WDC) according to charging rates valid for a given year.

Attention! If using liquid to water-cooled torches, utilize it according to attached information.

10. TROUBLESHOOTING



Not all problems with functioning of the device, are the evidence of failure. You can independently carry out an analysis in search of probable failure. In case of doubt, please contact to SPARTUS® dealer or authorized service center.



During the warranty period all repairs should be carried by authorized service center. Repairs carried out by unauthorized persons will void the warranty.

PROBLEMS WITH THE DEVICE

Turn ON power but the LCD display is not illuminated.	Switch, fuse or power cord damaged.
After welding machine is over-heat, the fan doesn't work.	Fan damaged. The cable is loose.
Press the microswitch in the handle, no output shielded gas.	No gas in the gas cylinder. Electromagnetic valve, control switch or control circuit damaged
Wire-feeder doesn't work.	Motor damaged. The idler roll is loose or weld wire skids. The drive roll doesn't fit with the diameter of weld wire. Wire feed pipe or tip is jammed.
No striking arc and no output voltage.	Output cable is connected incorrectly or loosen. Control circuit damaged.
Welding current is run away and can be not controlled.	The potentiometer or the control circuit damaged.

<i>MIG WELDING PROBLEMS</i>	
Excessive spatter.	Voltage or wire feed speed set too high.
	Wrong polarity set.
	Stick out too long.
	Contaminated base metal or wire.
Porosity – small cavities or holes resulting from gas pockets in weld metal.	Inadequate gas flow.
	Wrong gas or inadequate gas flow.
	Moisture on the base metal or wire.
	Gas nozzle clogged with spatter, worn or out of shape.
Wire stubbing during welding.	Missing or damaged gas diffuser.
	Welding voltage set too low.
No wire feed.	Wire speed set too high
	Wrong mode selected or torch selector switch.
Interrupted wire feed.	Wrong polarity selected.
	Incorrect wire speed or voltage setting.
	MIG gun lead too long, kinked or too sharp angle being held.
	Contact tip worn, wrong size, wrong type.
	Liner worn or clogged.
	Wire misaligned in drive roller groove.
	Incorrect drive roller size or wrong type of drive roller selected.
	Worn drive rollers.
	Drive roller pressure too high.
	Wire crossed over on the spool or tangled.
Contaminated MIG wire.	

TIG WELDING PROBLEMS

Tungsten burning away quickly.	Incorrect gas or no gas.
	Inadequate gas flow.
	Back cap not fitted correctly.
	Incorrect tungsten being used.
Porosity - poor weld appearance and color.	Wrong gas, poor gas flow, gas leak.
	Contaminated base metal or wire.
	Incorrect filler wire.
Arc difficult to start or will not start DC welding.	Incorrect machine set up.
	No gas or incorrect gas flow.
	Incorrect tungsten size or type.
	Loose connection.
	Earth clamp not connected to work.

MMA WELDING PROBLEMS

No arc.	Incomplete welding circuit.
	Wrong mode selected.
	No power supply.
Porosity – small cavities or holes resulting from gas pockets in weld metal.	Electrode or work piece dirty, contaminated or moisture.
	Incorrect arc length.
Excessive spatter.	Amperage too high.
	Incorrect arc length.
Weld sits on top, lack of fusion.	Insufficient heat input.
	Work piece dirty, contaminated or moisture.
Excessive penetration – burn through.	Excessive heat input.
	Incorrect travel speed.
Electrode welds with different or unusual arc characteristic.	Incorrect polarity.

Notes



EASY

Simple solutions and an attractive price – these are the features of SPARTUS® Easy series devices. Our equipment has been designed with ease of use and ergonomics at work in mind.

A masterly combination of high quality production, excellent parameters and ergonomics – these are features of the SPARTUS® Master series of devices, which were created with demanding welding jobs in mind.



MASTER



PRO

Precision, functionality, excellent parameters and resistance to high workloads – these are the features of the SPARTUS® Pro industrial series of devices. This series consists of specialised solutions which will satisfy even the most demanding users.



Videopresentation of products



Subscribe to the channel SPARTUS.INFO